



## Syn-Mar Shower Base Installation

Syn-Mar shower bases are equipped with a water dam (flange) around the outside edges. This base must be installed with the water dams directly against the wall studs. It is important to install your shower base before you apply the wallboard to the studs.

1. Test-fit the shower base to ensure drain location and proper fit before applying thin-set.
2. Remove the base and attach the drain to the shower base as instructed.
3. Apply a level layer of thin-set into the entire shower base cavity.
4. Using a ¼" trowel, spread the thin-set out to a level surface. Do NOT shim one side only.
5. Carefully place the shower base onto the thin-set and apply body weight to set in place, making sure that the base is level.
6. Allow 24 hours for thin-set to dry.

